Pre-Design and Project Layout Kozmo Ken Bates Kozmo@AquaKoz.com










































## VAP - Vertical Adjustment Potential

- Range of possible profiles for life of project
- Considerations
  - Existing profile
    - Controls, mobility, bedrock
    - Effect of old culvert
  - History and future of watershed
    - Hydrology, debris, sediment, incision / local scour

15

- Bankfull, floodplain
- Infrastructure to be protected
- If it's too wide, get help



























## Geomorphic Design - Kozmo Bates





















## Three design options - Premises

- Low-slope: The design of an oversized culvert in a low risk site can be simplified and built with little risk
- Hydraulic: A structure with appropriate hydraulic conditions will allow target species to swim through it.
- Stream Simulation: A channel that simulates characteristics of the adjacent channel, will present no more of a challenge to movement of organisms than that channel.

35